

Cummins exhaust manifold catalog

BT/CT/ISDe/ISZ		
001	3970066	6BT exhaust manifold
002	3917700	6BT exhaust manifold
003	3929779	6CT exhaust manifold
004	3929778	6CT for bus exhaust manifold
005	3906741	6CT Construction Machineryexhaust manifold
006	3907451	6CT Construction Machineryexhaust manifold
007	3943841+3937477	6L exhaust manifold
008	3979211	ISDE (6D) exhaust manifold
009	4939973	ISDE (4D) exhaust manifold
010	3906660	for Dongfeng Tianjin truck
011	4932577	4BT exhaust manifold
012	4988420	4BT Construction Machineryexhaust manifold
013	3901635	4BT Construction Machineryexhaust manifold
014	3863106	Construction Machineryexhaust manifold
015	3973422	Construction Machineryexhaust manifold
016	3976789	Construction Machineryexhaust manifold
017	3999806	Construction Machineryexhaust manifold
018	4946654	Construction Machineryexhaust manifold
019	3901223	Construction Machineryexhaust manifold
020	2831203	Construction Machineryexhaust manifold
021	3968362+3937478	Construction Machineryexhaust manifold
022	3943875+3943871	Construction Machineryexhaust manifold
023	3967750+3937630	Construction Machineryexhaust manifold
024	3967751+3937630	Construction Machineryexhaust manifold
025	3931744	Construction Machineryexhaust manifold
026	3901919	Construction Machineryexhaust manifold
027	3912600	Construction Machineryexhaust manifold
028	4938859	Construction Machineryexhaust manifold
029	3945189	Construction Machineryexhaust manifold
030	3968856	Construction Machineryexhaust manifold
03	3971934	Construction Machineryexhaust manifold
032	3943869	Construction Machineryexhaust manifold
033	3955459	Construction Machineryexhaust manifold
034	4316767	ISZ13 exhaust manifold middle enhanced

035	4316768	ISZ13 exhaust manifold middle enhanced
036	4365900	ISZ13 exhaust manifoldside enhanced
037	5612673	ISZ14 exhaust manifold enhanced
038	3693170	ISG exhaust manifold enhanced
039	5662933	X13 exhaust manifold enhanced
040	5614253	Euro-6 exhaust manifold enhanced
ISM exhaust manifold		
041	3104237	ISM exhaust manifold middle
042	4999619	ISM exhaust manifold middle
043	4999607	ISM exhaust manifold middle
044	3335152	ISM exhaust manifold middle
045	4003994	ISM exhaust manifoldside
X15 exhaust manifold		
046	ISX15	3100131 middle+3680200 side exhaust manifold
047	ISX15	4386579 middle+4386627 side exhaust manifold
048	ISX15	3680199 middle+3680200 sideexhaust manifold
049	ISX15	3104190 middle+3682549 side exhaust manifold
050	ISX15	4386668 middle+3683870 side exhaust manifold
QST30 exhaust manifold		
051	4295291	for Construction Machinery exhaust manifold middle
052	4295293	for Construction Machinery exhaust manifold middle
053	3092660	for Construction Machinery exhaust manifold middle
054	3092659	for Construction Machinery exhaust manifold middle
055	3092657	for Construction Machinery exhaust manifold side
056	3092658	for Construction Machinery exhaust manifold side